

























Peroxide Bath Instructions

Mix 1 part 20% Clear Peroxide to 5 parts water. Use clear plastic containers with a clear lid. Soak plastic parts in the peroxide solution, weighting down the parts with stainless steel weights. Using normal steel will rust and stain the parts. A clear sunny day works well. Always wear rubber gloves and goggles. The solution can be reused, just put it back into the plastic container for next time.

SalonCare™
PROFESSIONAL

20
VOLUME
CLEAR

STABILIZED FORMULA

20 VOLUME CLEAR DEVELOPER
RÉVÉLATEUR TRANSPARENT 20 VOLUMES
REVELADOR TRANSPARENTE DE 20 VOLUMENES
3.78 L 128 fl. oz. (1 Gallon U.S.)